

## Removing and installing right (front passenger side) heat exchanger



### Note


Observe the following sequence for right-hand drive vehicles: Start by removing the left heat exchanger.

Removal of the left heat exchanger on left-hand drive vehicles involves taking out the right heat exchanger beforehand.

### Removing

- Perform preparatory work for heat exchanger removal → [Chapter](#).
- Remove the glove compartment: → [General body repairs, interior; Rep. gr.68](#)
- Remove the footwell vent.
- Cover the floor covering in the area beneath the heat exchanger with impermeable sheeting and absorbent paper.

Apply a small quantity of silicone lubricant to the contact surface of both coolant pipes -D- and -E- at the socket -C- from inside as well (to enable the pipes to be moved without altering the position of the socket; this illustration shows the pipes viewed from the plenum chamber).




- Remove the clamps -A- and -B-.
- Take both coolant pipes out of the heat exchanger.
- Slide both coolant pipes towards the „plenum chamber“.



### Note

As the socket has been moistened with a small quantity of silicone lubricant in the area of the coolant pipe penetration, the pipes can be moved without pushing the socket out of the air conditioning unit.

- Screw out the bolts -C-.
- Detach the holder.
- Pull the heat exchanger -D- out of the air conditioning unit.



### Installing

- Before installing the heat exchanger, check the condensation drain openings

-A- for dirt and clean if necessary.



Note

- t The condensation drain must not be blocked by dirt or other deposits.
- t The Fig. shows the drain openings with heat exchangers in position.


Cleaning condensation drain:

Heat exchanger removed: Use an illuminated angled mirror to check both – drain openings by way of the opening for the heat exchanger and clean the condensation drains if necessary with a piece of wire for example.

Heat exchanger fitted: Use a piece of – wire for example to clean the condensation drains from outside (with the condensation hose detached).

Perform the remaining installation operations in reverse order, paying attention to the following:

- Check the attached foam seal before installing the heat exchanger.



Note

If not properly affixed, the seal may t curl up on insertion of the heat exchanger in the air conditioning unit.


Cold air may flow past the heat t exchanger if the seal is damaged or not properly fitted.

Secure all connections with standard – clips or clamps approved for this connection: → [Electronic parts catalogue](#)




Note

- t The clips -A- and -B- are difficult to fit with the unit installed.



To permit service replacement of the heat exchangers with the air conditioning unit fitted, use is to be made of the clamps -A- and -C- → [Electronic parts catalogue](#).




- Check both coolant pipes -B- and the connections at the heat exchanger -C- for damage or contamination.



#### Note

Always replace sealing rings.

- Moisten the sealing ring -A- with a small quantity of coolant and attach the sealing ring to the coolant pipe -B-.
- Attach the clamp -A- (with studs) as shown to the connection at the heat exchanger -B-.
- Attach the clamp -C- (with holes) as shown to the coolant pipe -D-.
- Insert the coolant pipe -D- (with sealing ring) in the connection of the heat exchanger -B-.
- Secure the coolant pipe in position in the heat exchanger with the two clamps -C- and -D-.
- Tighten the two hexagon nuts -A- and -B- alternately and evenly (tightening torque 3 Nm).



#### Note

- The clamps -C- and -D- must be fitted as shown (pay attention to outer contour).
- Take care to keep the clamps straight when tightening the hexagon nuts.
- Check the position of the clamps after securing the coolant pipes (they must not make contact with other components).

- Fit the second coolant pipe in the same manner.
- Before fitting the glove compartment, check the cooling system for leaks:  
→ [Engine, mechanics; Rep. gr.19](#)

- Before fitting the glove compartment and plenum chamber cover, check the position of the socket in the coolant pipe penetration to the plenum chamber.

- Bleed the cooling circuit before plugging in the 2-pin connector to the coolant circulation pump -V50- of the pump valve unit → [Chapter](#) and → [Engine, mechanics; Rep. gr.19](#)



**Note**

- t The coolant circulation pump -V50- of the pump valve unit is not to be started up until the coolant circuit has been bled (dry running of the pump in the pump valve unit would cause destruction).

- t When bleeding the coolant circuit, take special care to ensure complete bleeding of the heat exchangers. If air bubbles remain in the heat exchangers, complaints may be received about a lack of heat output in winter or differences in the temperature of the air flowing out of the vents with the same setting in control mode → [Chapter](#).

