

Capacities - rear final drive 0BF



Caution

Gear oil and ATF change

- On some RS models, the gear oil and the ATF must be changed.
- For change interval, refer to → [Maintenance tables](#).
- For all other vehicles no change is required.

Rear final drive	0BF
Gear oil capacity <ul style="list-style-type: none"> ◆ For final drive (differential and pinion shaft) ◆ No change required, except for RS models ◆ Change interval for RS models → Maintenance tables ◆ → Chapter „Checking gear oil level“ ◆ → Chapter „Draining and filling gear oil“ 	0.95 ltr.
Gear oil specification	→ Electronic parts catalogue
ATF capacity <ul style="list-style-type: none"> ◆ For hydraulic control unit and superposition gears ◆ No change required, except for RS models ◆ Change interval for RS models → Maintenance tables ◆ → Chapter „Checking ATF level“ 	approx. 0.85 litres

♦ → Chapter „Draining and filling ATF“	
ATF specification	→ Electronic parts catalogue